

ACCQPrep[®] Quick Start Guide

Overview

Two requirements must be met before these quick start instructions can be used to successfully operate the ACCQPrep system:

- The operator must be familiar with the safety warnings at the beginning of the *ACCQPrep Operation Guide*.
- The system must be installed according to the installation instructions in the *ACCQPrep Installation Guide*.

Note

For the most reliable operation, priming the system each morning is recommended.

Column Installation and Configuration

1. Install and connect the appropriate preparative HPLC column using the associated column mounting brackets onto the column rails on the right side of the ACCQPrep system.



Figure 1: ACCQPrep column rails

2. If the column has not previously been used on the instrument, add the column to the column list. If the column is already on the list, skip ahead to the instructions for running a method.
 - a. To add the column to the list, select **TOOLS > CONFIGURATION**. The **CONFIGURATION** window opens (Figure 2).
 - b. Select the **PREP HPLC** tab, then press **NEW**.
 - c. Enter a name to identify your column.
 - d. Enter the parameters associated with your column.
 - e. Press **SAVE**.
 - f. If you would like to create methods to associate with this column, press **DEFINE METHODS**.

- g. After the column is saved, select it as the Default column. If your system has a Column Selector Valve, choose the correct position that the column is installed on. Repeat Step 2 for adding any additional columns.

- h. For more details, see the Operation chapter of the *ACCQPrep Operation Guide*.




Figure 2: The CONFIGURATION window

Note

The DEFAULT COLUMN is automatically displayed in the COLUMN window on the RUN screen at start up (Figure 3).

Note

When doing manual injection, never load more than 50% of the total loop volume (i.e., 2.5 mL in 5 mL loop) to prevent any sample loss. When using an AutoInjector or AutoSampler, follow any on-screen warnings regarding injection volume.

Running a Method

1. On the **RUN** screen, the default column will be displayed in the **COLUMN** field.
2. Press the **DOWN** arrow in the **COLUMN** list to select a different column (Figure 3). If you have a Column Selector Valve, only the installed columns for each of the four positions are shown. Choose a method associated with the column being used.
3. Edit the method (gradient length, detection options, etc.) using the **METHOD EDITOR** tab or by modifying the gradient profile on the **MAIN** screen. See the Method Editor section of the *ACCQPrep Operation Guide* for details.
4. On the **MAIN** screen, press **START** to begin a purification run.



